



### CRITICAL TIPS FOR OPTIMUM PERFORMANCE



DO NOT THIN, ADD WATER OR ADDITIONAL PAINT TO INCREASE COVERAGE



DO NOT APPLY WITHOUT AN INITIAL COAT OF PERMABOND (**sold separately**)



TWO UNIFORM HEAVY COATS ARE REQUIRED



PRECIPITATION, HEAVY DEW OR SPRINKLER COVERAGE WITHIN 24 HOURS OF APPLICATION WILL PROMOTE FILM FAILURE



DO NOT APPLY IF TEMPERATURE IS BELOW 60° F OR ABOVE 85° F



AGITATION DURING APPLICATION IS NECESSARY



ALLOW AT LEAST 2 CONSECUTIVE DAYS OF DRY WEATHER AFTER CLEANING OR PRECIPITATION BEFORE APPLYING.